



AGE 3+
7469

Escape the Snake Playset



ASSEMBLY: Adult assembly required.

- 1) Attach tail spinner to tail section.
- 2) Fit tail section onto play base.
- 3) Fit loop extension piece onto play base.
- 4) Fit main loop unit onto play base assembly.
- 5) Connect track pieces together with track connectors, then connect track to play base.
- 6) Connect vehicle launcher to track, making sure that the launcher faces front of snake.



VEHICLE LAUNCHING INSTRUCTIONS:

- 1) Turn wind-up key to start tail-spinning action.
- 2) Pull launcher back and hold.
- 3) Place vehicle on track with back end touching launcher.
- 4) Hold down tab, then release launcher.



Note: Launcher should only be used with track and playset attached.

Not all additionally purchased cars will work with this playset.
Product and colors may vary.
Please keep company details for future reference.

© Disney.
® and/or TM & © 2002 Hasbro. All Rights Reserved.
® denotes Reg. U.S. Pat. & TM Office
7469 PN 6200180000



Questions? Call: 1-800-327-8264